

Diversey™

TM

suma®

San Conc



D4a
conc

Sanitiser - Concentrate

Description

Suma® San Conc D4a conc is a concentrated sanitiser for use on all hard surfaces including food contact surfaces in food premises. Suma® San Conc D4a conc is also suitable for laundry sanitising.

Features

Suma® San Conc D4a conc is a concentrated liquid sanitiser. The optimal blend of Quaternary Ammonium Compound and wetting agents in Suma San Conc D4a conc makes it very effective as a sanitiser against a wide spectrum of micro-organisms, in all water conditions. The product can be used as a no-rinse sanitiser when diluted to an in-use concentration of <200ppm Quaternary Ammonium Compound (AU only).

For dosing accuracy Suma® San Conc D4a conc should be dosed via the Diversey Divermite dosing system.

Benefits

- Effective against a wide spectrum of micro-organisms, helping to improve hygiene security.
- Effective in all water conditions.
- Safe for use on all surfaces including aluminium.
- Can be used for no-rinse application (AU only).
- Concentrated formula provides economy in use and reduces packaging waste.
- Suitable for laundry sanitising where required temperatures are unable to be reached.

Application areas

- Hospitality
- Lodging
- Healthcare
- Food Service





Diversey™



suma®

San Conc



D4a
conc

Sanitiser - Concentrate

Directions for use

Spray Sanitising

For soiled areas, always pre-clean with a Diversey detergent and rinse with water

1. Fill up the bottle with water. Insert the bottle in the Divermite dispenser and push once (3ml/750ml)
2. Spray surface and leave for 60 seconds.
3. Wipe surface with clean paper towel and allow to air dry.
4. Direct contact with prescribed goods must be prevented and treated surfaces adequately drained before processing operations resume.

A made up spray bottle of product will be active for up to seven days. Rinse and dry bottle before refilling.

Surface Sanitising

For soiled areas, always pre-clean with a Diversey detergent and rinse with water

1. Use at a concentration of 4 pushes (12ml) in 3L cool water.
2. Apply solution with cloth or brush to surface or soak item.
3. Leave for 60 seconds.
4. Drain or wipe surface with clean paper towel and allow to air dry.
5. Direct contact with prescribed goods must be prevented and treated surfaces adequately drained before processing operations resume.

Laundry Sanitising

Dose Suma® San Conc D4a conc into the final rinse cycle of the washing machine. Please consult your Diversey representative for further application advice.

In New Zealand only: A rinse with potable water after application is required when the product is used by operators processing non-dairy animal products who are operating under the Animal Products Act (APA) regime. Fish processing plants are excluded from this requirement.

Microbiological Data

Suma® San Conc D4a conc tested at a dilution of 3ml/750ml (200ppm) and in clean conditions, 60 seconds contact time gave the following reduction in organisms.

	% reduction organisms
Esherichia coli	>99.99%
Staphylococcus aureus	>99.99%
Salmonella choleraesuis	>99.999%
Listeria monocytogenes	>99.999%



Diversey™



suma®

San Conc



D4a
conc

Sanitiser - Concentrate

Technical information

Appearance	Dark purple, clear liquid	Specific gravity	1.0
pH (1% solution)	3.0 – 4.0	Dilution	3ml/750ml

The above data is typical of normal production and should not be taken as a specification.

Product	Pack size	SKU Code	Availability
Suma® San Conc D4a conc	2 x 1.5L	7522995	AU & NZ

Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet. Store in original container. Avoid extremes of temperature and humidity.

Product compatibility

Under recommended conditions of use, Suma® San Conc D4a conc is suitable for use on most materials commonly encountered in the kitchen.

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at www.diversey.com or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:
Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 www.diversey.com

© 2018 Diversey, Inc. All Rights Reserved.

Dec-18